

Duše



...VS1 = poloha ventilku 90° – 90°
 ...VS2 = poloha ventilku 90° – 30°



Duše	Průměr kola mm	Šířka kola mm	Nafukovací kolo Palce
S-150-30-VS2 Id. č.: 0023669	150	30	6 x 1 1/4
S-185-45-VS2 Id. č.: 0023670	185	45	7 x 1 3/4
S-200-50-VS1 Id. č.: 0030434	200	50	8 x 2
S-200-50-VS2 Id. č.: 0023673	200	50	8 x 2
S-210-65-VS1 Id. č.: 0023674	210	65	8 x 2
S-220-50-VS1 Id. č.: 0023675	220	50	8 x 1/32 x 2
S-220-120-VS2 Id. č.: 0024586	220	120	8 x 1/2 x 2
S-230-65-VS2 Id. č.: 0039612	230	65	2,50-4
S-230-65-VS1 Id. č.: 0023676	230	65	2,50-4
S-260-85-VS2 Id. č.: 0011393	260	85	3,00-4
S-260-85-VS1 Id. č.: 0023677	260	85	3,00-4
S-310-50-VS2 Id. č.: 0023679	310	50	12 1/2 x 2 1/4
S-300-100-VS1 Id. č.: 0023680	300	100	4,00-4
S410-100-VS2 Id. č.: 0023681	410	100	4,00-8
S-400-100-VS2 Id. č.: 0023682	400	100	4,80/4,00-8
S-400-100-VS1 Id. č.: 0037363	400	100	4,80/4,00-8
S-460-140-VS2 Id. č.: 0023683	460	140	5,00-8